



---

---


---

---

---

---

---



---

---


---

---

---

---

---



---

---


---

---

---

---

---




---

---

---


---

---

---

---

---




---

---

---


---

---

---

---

---




---

---

---

---

---


---

---


---

Lamp Light Sources Gas discharge lamps

High Pressure Mercury Lamps  
(High Intensities concentrated in specific lines)



There are strong lines near 254nm, 297nm, 333nm, 365nm, 405nm, 436nm, 546nm and 568nm



---

---

---

---


---

---


---


---

Lamp Light Sources Gas discharge lamps



UV Handlamps usually provide for "short – 254nm" or "long – 365nm" illumination





---

---

---

---

---

---


---

---

Lamp Light Sources

Mercury-Xenon Arc Lamp (greater intensities in the UV)

Figure 5: Spectral Distribution of Various Lamps



---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---

---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---




---

---

---

---

---

---

---

---

### Detectors

The photoelectric effect was discovered by Heinrich Hertz in 1886

Specifically he noticed that a charged object loses its charge more readily when it is illuminated by UV light

It was soon discovered that the energies of the ejected electrons were independent of the intensity of the illuminating light, whereas this energy increased with the frequency of the light. This phenomenon as explained by Einstein in 1905 as being due to the quantum nature of light, i.e., photons. Einstein received his Nobel Prize for this work in 1921.

---

---

---

---

---

---

---

---

### Detectors

#### PMT Types

a) Side-On Type

b) Head-On Type

APD

The silicon avalanche photodiode (Si APD) has a fast time response and high sensitivity in the near infrared region. APDs can be purchased from Hamamatsu with active areas from 0.2 mm to 5.0 mm in diameter and low dark currents (selectable). Photo courtesy of Hamamatsu

---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---

---

---

---

---

---

**Detectors**

APDs are usually used in applications characterized by low light levels

The silicon avalanche photodiode (Si APD) has a fast time response and high sensitivity in the near infrared region. APDs can be purchased from Hamamatsu with active areas from 0.2 mm to 5.0 mm in diameter and low dark currents (selectable). *Photo courtesy of Hamamatsu*

---

---

---


---

---

---

---

---



---

---

---

---


---

---

---

---





---

---


---

---

---

---

---



---

---


---

---

---

---

---



---

---


---

---

---

---

---




---

---

---


---

---

---

---

---




---

---

---


---

---

---

---

---




---

---

---

---

---

---

---

---

The earliest commercial fluorescence instruments were essentially attachments for spectrophotometers such as the Beckman DU spectrophotometer; this attachment allowed the emitted light (excited by the mercury vapor source through a filter) to be reflected into the spectrophotometer's monochromator. The first description of this type of apparatus was by R.A. Burdett and L.C. Jones in 1947 (J. Opt. Soc. Amer. 37:554).






FIG. 20. Attachment for measuring fluorescence spectra with the Beckman Model DU and DK spectrophotometers.

The problem with prisms, however, was that the light dispersion was not linear with wavelength and normal glass prisms did not pass UV light – so expensive quartz prism had to be used. For these reasons grating based systems became more popular.

### Diffraction Gratings




**GRATING EQUATION**  
 $n\lambda = d(\sin\theta_i \pm \sin\theta_r)$   
 $n$  = order of diffraction  
 $d$  = grating constant  
 $\lambda$  = diffracted wavelength




Formerly ruled with diamond-tipped instruments

Now almost always made using a holographic, photolithographic technique or a photosensitive gel method




<http://gratings.newport.com/products/supplemental/types.asp>

### Monochromators



1. Slit Width (mm) is the dimension of the slits.
2. Bandpass is the FWHM of the selected wavelength.
3. The *dispersion* is the factor to convert slit width to bandpass.



---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---


---

---

---

---

---



---

---

---

---

---

---

---

---

How do we handle highly absorbing solutions?

Quartz/Optical Glass/Plastic Cells

Excitation

Emission

Emission Path Length

Detector

Excitation Path Length

Type 1

Type 2

Type 3

4 Position Turret  
SPEX Fluoromax-2, Jobin-Yvon

---

---

---

---

---

---

---

---

Front Face Detection

Triangular Cells

Excitation

Emission

Detector

Reflected Excitation & Emission

Thin Cells & Special Compartments

IBH, Glasgow G3 8JU  
United Kingdom

[1]

Absorbance Measurements

---

---

---

---

---

---

---

---

Lifetime Instrumentation

Decay curve

Phase shift plot

Frequency plot

---

---

---

---

---

---

---

---



## Light Sources for Decay Acquisition: Frequency and Time Domain Measurements

### Pulsed Light Sources (frequency & pulse widths)

## Mode-Locked Lasers

ND:YAG (76 MHz) (150 ps)  
Pumped Dye Lasers (4 MHz Cavity Dumped, 10-15 ps)  
Ti:Sapphire lasers (80 MHz, 150 fs)  
Mode-locked Argon Ion lasers


## Directly Modulated Light Sources

- Diode Lasers (short pulses in ps range, & can be modulated by synthesizer)
- LEDs (directly modulated via synthesizer, 1 ns, 20 MHz)
- Synchrotron Radiation


## Flash Lamps


Thyratron-gated nanosecond flash lamp (PTI), 25 KHz, 1.6 ns  
Coaxial nanosecond flashlamp (IBH), 10Hz-100kHz, 0.6 ns

## Modulation of CW Light Use of a Pockel's Cell



## Time Correlated Single Photon Counting





---

---

---


---

---

---

---

---



---

---

---

---

---

---

---

---